




## Pedestal Count And Spacing For Standard Maple Benches



Recommended pedestal locations apply to all pedestal types except as noted. For pedestal spacing on custom benches, contact engineering for guidance. Hardware for attachment to benches is included with pedestals. Pilot holes must be drilled by the installer/end-user. Use appropriate hardware (not included) for anchoring pedestals to the floor.

**ROBINSON STEEL CO.**  
Locker, Storage Solutions  
and Restroom Supplies  
at the Right Price!



Phone: (610) 279-6600  
Fax: (610) 279-6646  
Toll free: (800) 275-6702  
Email: [sales@rsclackers.com](mailto:sales@rsclackers.com)